

Section 48. Comparator with Blanking

HIGHLIGHTS

This section of the manual contains the following major topics:

48.1	Introduction	
48.2	Comparator Registers	
48.3	Comparator Operation	
48.4	Comparator Configuration	
48.5	Comparator Interrupts	
48.6	Comparator Voltage Reference Generator	
48.7	Register Map	
48.8	Design Tips	
48.9	Related Application Notes	
48.10	Revision History	

48

Note: This family reference manual section is meant to serve as a complement to device data sheets. Depending on the device variant, this manual section may not apply to all PIC24F devices.

Please consult the note at the beginning of the **"Comparator"** chapter in the current device data sheet to check whether this document supports the device you are using.

Device data sheets and family reference manual sections are available for download from the Microchip Worldwide Web site at: http://www.microchip.com

48.1 INTRODUCTION

The PIC24F Comparator with Blanking module provides multiple comparators that can be configured in different ways. Individual comparator options are specified by the Comparator with Blanking module's Special Function Register (SFR) control bits. The SFRs control bits associated with Comparator with Blanking module allow users to:

- · Select the edge for trigger and interrupt generation
- Select low-power control
- Configure the comparator voltage reference and band gap
- Configure output blanking and masking

The comparator operating mode is determined by the input selections (that is, whether the input voltage is compared to a second input voltage, to an internal voltage band gap reference, or to an internal reference voltage). The internal reference voltage is generated by a resistor ladder network that is configured by the Comparator Voltage Reference Control register (CVRCON) (see Register 48-6).



Figure 48-1: Input Selection Logic Block Diagram

Figure 48-2: Digital Filter Interconnect Block Diagram



48.2 COMPARATOR REGISTERS

The Comparator with Blanking module uses the following six registers:

CMSTAT: Comparator Status Register

This register enables control over the operation of all comparators when the device enters ldle mode. In addition, it provides the status of all comparator results, as well as all of the comparator outputs and event bits, which are replicated as read-only bits in the CMSTAT register.

• CMxCON: Comparator Control Register (where x = 1, 2, or 3)

This register allows the application program to enable, configure and interact with the individual comparators.

CMxMSKSRC: Comparator Mask Source Select Control Register

This register allows the application program to select sources for the inputs for the blanking function.

- CMxMSKCON: Comparator Mask Gating Control Register
- This register allows the application program to specify the blank function logic.
- CMxFLTR: Comparator Filter Control Register

This register enables comparator filter configuration.

CVRCON: Comparator Voltage Reference Control Register

This register allows the application program to enable, configure and interact with the comparator internal voltage reference generator (for more information, see **48.6 "Comparator Voltage Reference Generator**").

Register 48-1	CMSTAT: C	Comparator St	atus Registe	er					
R/W-0	U-0	U-0	U-0	U-0	R-0	R-0	R-0		
CMSIDL		—	_	—	C3EVT	C2EVT	C1EVT		
bit 15							bit 8		
U-0	U-0	U-0	U-0	U-0	R-0	R-0	R-0		
_	—	—	_	_	C3OUT	C2OUT	C1OUT		
bit 7			-1				bit 0		
Legend:									
R = Readable	bit	W = Writable	bit	U = Unimple	emented bit, read	d as '0'			
-n = Value at I	POR	'1' = Bit is se	t	'0' = Bit is cl	eared	x = Bit is unk	nown		
bit 15	CMSIDI · Str	op in Idle Mode	hit						
	1 = Discontir	-	f all compara		ce enters Idle m	ode			
bit 14-11		nted: Read as	-						
bit 10	-	nparator 3 Ever							
511 10		ator event occu							
	-								
bit 9	0 = Comparator event did not occur C2EVT: Comparator 2 Event Status bit								
Sit 9	1 = Comparator event occurred								
	0 = Comparator event did not occur								
bit 8	C1EVT: Comparator 1 Event Status bit								
bit 0	1 = Comparator event occurred								
	-	ator event did n							
bit 7-3		nted: Read as							
bit 2	-	nparator 3 Outp							
DIL Z	When CPOL	-	Jui Status Di						
	$\frac{1}{1} = V_{IN} + > V$								
	0 = VIN + < V								
	When CPOL	= 1:							
	$\frac{\text{When CPOL} = 1}{1 = \text{Vin} + < \text{Vin}}$								
	0 = VIN+ > V	IN-							
bit 1	C2OUT: Con	nparator 2 Outp	out Status bit						
	When CPOL								
	1 = VIN + > V								
	0 = VIN + < VIN -								
	When CPOL								
	1 = VIN + < V	IN-							
	$\Theta = VIN + > V$	IN-							
bit 0	C1OUT: Con	nparator 1 Outp	out Status bit						
	When CPOL	. = 0:							
	$1 = V_{IN} + > V$								
	0 = VIN+ < V	IN-							
	When CPOL	. = 1:							
	1 = VIN+ < V	IN-							
	0 = VIN+ > V	IN-							

Register 48-1:	CMSTAT: Comparator Status Register
----------------	------------------------------------

R/W-0	R/W-0	R/W-0	R/W-0	U-0	U-0	R/W-0	R-0		
CON	COE	CPOL	CLPWR			CEVT	COUT		
bit 15							bit 8		
R/W-0	R/W-0	U-0	R/W-0	U-0	U-0	R/W-0	R/W-0		
)L<1:0>		CREF				<1:0>		
bit 7			GIVEN				bit		
Legend:									
R = Readable	e bit	W = Writable	bit	U = Unimpler	mented bit, read	d as '0'			
-n = Value at		'1' = Bit is se		'0' = Bit is cle		x = Bit is unkr	nown		
			-				-		
bit 15	CON: Compa	rator Enable b	oit						
	1 = Comparat 0 = Comparat								
bit 14	COE: Compa	rator Output E	nable bit						
		tor output is pr tor output is in	esent on the C ternal only	xOUT pin					
bit 13	CPOL: Comp	arator Output	Polarity Select	bit					
		tor output is in tor output is no							
bit 12	CLPWR: Comparator Low Power Mode Select bit								
			low-power mo perate in low-po						
bit 11-10	Unimplemen	ted: Read as	'0'						
bit 9	CEVT: Comparator Event bit								
	interrupts	tor event acco until the bit is tor event did n	cleared	_<1:0> setting	s occurred; disa	ables future trig	gers and		
bit 8	•	arator Output							
bit o	When CPOL	= 0 (non-inver							
	$1 = V_{\rm IN} + > V_{\rm II}$								
	$0 = V_{IN} + < V_{IN}$								
	$\frac{\text{When CPOL} = 1 \text{ (inverted polarity):}}{1 = \text{VIN} + < \text{VIN}}$								
	0 = VIN + > VII	N-							
bit 7-6			t/Interrupt Pola	-					
	10 = Trigger/f compara If CPOL :	Event/Interrupt ator output (wh = 1 (inverted p	generated only nile CEVT = 0) polarity):	y on high to lo		or output (while the polarity-sele			
	If CPOL : High-to-lo	Low-to-high transition of the comparator output If CPOL = 0 (non-inverted polarity): High-to-low transition of the comparator output							
	compara If CPOL :	ator output (wh = 1 (inverted p	nile CEVT = 0)		gh transition of t	the polarity-sele	ected		
	-	= 0 (non-inver	-						
			of the comparat	or output					

Register 48-2: CMxCON: Comparator Control Register

- bit 5 Unimplemented: Read as '0'
- bit 4 **CREF:** Comparator Reference Select bit (VIN+ input) 1 = VIN+ input connects to internal CVREFIN voltage 0 = VIN+ input connects to CXINA pin
- bit 3-2 Unimplemented: Read as '0'
- bit 1-0 CCH<1:0>: Comparator Channel Select bits
 - 11 = VIN- input of comparator connects to INTREF
 - $10 = V_{IN}$ input of comparator connects to C×IND pin
 - 01 = VIN- input of comparator connects to CXINC pin
 - 00 = VIN- input of comparator connects to CXINB pin

U-0	U-0	U-0	U-0	R/W-0	R/W-0	R/W-0	RW-0
_	_		_			CC<3:0>	-
bit 15							bit 8
R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
	SELSRC	CB<3:0>			SELSR	CA<3:0>	
bit 7							bit 0
Legend:							
R = Readabl	le bit	W = Writable I	bit	U = Unimplen	nented bit, rea	d as '0'	
-n = Value at		'1' = Bit is set		'0' = Bit is cle		x = Bit is unkr	nown
bit 15-12	Unimplemen	ted: Read as '	0'				
bit 11-8	SELSRCC<3	: 0>: Mask C In	put Select bi	ts			
	1111 = FLTA						
	1110 = Rese						
	1101 = Rese						
	1100 = Rese 1011 = Rese						
	1011 – Reserved						
	1001 = Reserved						
	1000 = Rese	rved					
	0111 = Rese	rved					
	0110 - Dooo	nuch					
	0110 = Rese						
	0101 = PWM	I1H3					
	0101 = PWM 0100 = PWM	11H3 11L3					
	0101 = PWM 0100 = PWM 0011 = PWM	11H3 11L3 11H2					
	0101 = PWM 0100 = PWM	11H3 11L3 11H2 11L2					
	0101 = PWM 0100 = PWM 0011 = PWM 0010 = PWM	11H3 11L3 11H2 11L2 11H1					
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0010 = PWM 0001 = PWM 0000 = PWM	11H3 11L3 11H2 11L2 11H1	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0010 = PWM 0001 = PWM 0000 = PWM	11H3 11L3 11H2 11L2 11H1 11L1 11L1 : :0>: Mask B Inj	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0010 = PWM 0001 = PWM 0000 = PWM SELSRCB<3	11H3 11L3 11H2 11L2 11H1 11L1 3 :0>: Mask B In	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese	11H3 11L3 11H2 11L2 11H1 11L1 c:0>: Mask B In rved rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1100 = Rese	11H3 11L3 11H2 11L2 11H1 11L1 :0>: Mask B In rved rved rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1100 = Rese 1011 = Rese	11H3 11L3 11H2 11L2 11H1 11L1 :0>: Mask B In rved rved rved rved rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1100 = Rese 1011 = Rese 1010 = Rese	11H3 11L3 11H2 11L2 11H1 11L1 :0>: Mask B In rved rved rved rved rved rved rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1001 = Rese 1010 = Rese 1001 = Rese	11H3 11L3 11H2 11L2 11H1 11L1 :0>: Mask B In rved rved rved rved rved rved rved rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1100 = Rese 1011 = Rese 1010 = Rese	11H3 11L3 11H2 11L2 11H1 11L1 :0>: Mask B In rved rved rved rved rved rved rved rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1001 = Rese 1001 = Rese 1001 = Rese 1000 = Rese	11H3 11L3 11H2 11L2 11H1 11L1 ::0>: Mask B In rved rved rved rved rved rved rved rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1011 = Rese 1011 = Rese 1001 = Rese 1001 = Rese 0111 = Rese 0111 = Rese 0111 = Rese	11H3 11H3 11H2 11H2 11H1 11L1 :0>: Mask B In rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1011 = Rese 1011 = Rese 1001 = Rese 1000 = Rese 0111 = Rese 0111 = Rese 0111 = Rese	11H3 11H3 11H2 11H2 11H1 11L1 :0>: Mask B In rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1011 = Rese 1011 = Rese 1001 = Rese 0111 = PWM 0100 = PWM	11H3 11H3 11H2 11H2 11H1 11H1 11H1 ::0>: Mask B In rved	put Select bi	ts			
bit 7-4	0101 = PWM 0100 = PWM 0011 = PWM 0001 = PWM 0000 = PWM SELSRCB<3 1111 = FLTA 1110 = Rese 1101 = Rese 1011 = Rese 1011 = Rese 1001 = Rese 1000 = Rese 0111 = Rese 0111 = Rese 0111 = Rese	11H3 11H3 11H2 11H2 11H1 11L1 ::0>: Mask B In rved rved rved rved rved rved rved rved rved rved 1H3 11H3 11H2 11L2	put Select bi	ts			

Register 48-3: CMxMSKSRC: Comparator Mask Source Select Control Register

Register 48-3:	CMxMSKSRC: Comparator Mask Source Select Control Register (Continued)

- bit 3-0 SELSRCA<3:0>: Mask A Input Select bits
 - 1111 = FLTA 1110 = Reserved 1101 = Reserved 1100 = Reserved 1011 = Reserved 1010 = Reserved 1001 = Reserved 1000 = Reserved 0111 = Reserved 0110 = Reserved 0101 = PWM1H3 0100 = PWM1L3 0011 = PWM1H2 0010 = PWM1L2 0001 = PWM1H1 0000 = PWM1L1

R/W-0 HLMS bit 15 R/W-0	U-0 —	R/W-0 OCEN	R/W-0 OCNEN	R/W-0 OBEN	R/W-0 OBNEN	R/W-0 OAEN	R/W-0 OANEN			
bit 15		OCEN	OCNEN	OBEN	OBNEN	OAFN				
						0/10/1	OANLIN			
R/W-0						•	bit 8			
	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0			
NAGS	PAGS	ACEN	ACNEN	ABEN	ABNEN	AAEN	AANEN			
bit 7							bit 0			
Legend:										
R = Readable b	bit	W = Writable	bit	U = Unimpler	mented bit, read	as '0'				
-n = Value at P	OR	'1' = Bit is se	t	'0' = Bit is cle		x = Bit is unk	nown			
bit 15	HLMS: High	or Low Level N	Aasking Select	bits						
	1 = The mask	king (blanking)	function will pre	event any asse	rted ('0') compa	rator signal from	n propagatir			
	0 = The mas	king (blanking)	function will pre	event any asse	rted ('1') compa	rator signal from	n propagatir			
bit 14	Unimplemen	nted: Read as	'0'							
bit 13		•	verted Enable	bit						
		onnected to OF	0							
	0 = MCI is not connected to OR gate									
bit 12		-	Inverted Enable	DIT 9						
	 1 = Inverted MCI is connected to OR gate 0 = Inverted MCI is not connected to OR gate 									
bit 11	OBEN: OR Gate B Input Inverted Enable bit									
	1 = MBI is co	onnected to OF	gate							
bit 10	OBNEN: OR	Gate B Input I	nverted Enable	e bit						
		MBI is connect MBI is not con	ed to OR gate nected to OR g	ate						
bit 9	OAEN: OR O	Gate A Input Er	nable bit							
		onnected to OF ot connected to	•							
bit 8	OANEN: OR Gate A Input Inverted Enable bit									
		MAI is connect MAI is not con	ed to OR gate nected to OR g	ate						
bit 7	 NAGS: Negative AND Gate Output Select 1 = Inverted ANDI is connected to OR gate 0 = Inverted ANDI is not connected to OR gate 									
bit 6	1 = ANDI is a	ive AND Gate connected to O not connected t	R gate							
bit 5			ut Inverted Ena	able bit						
	1 = MCI is co	onnected to AN ot connected to	ID gate							
bit 4	1 = Inverted	MCI is connec	nput Inverted E ted to AND gate nected to AND	е						
			_	-						
bit 3	ABEN: AND	Gate A1 B Inp	ut Enable bit							

Register 48-4: CMxMSKCON: Comparator Mask Gating Control Register

Register 48-4: CMxMSKCON: Comparator Mask Gating Control Register (Continued)

bit 2	ABNEN: AND Gate A1 B Input Inverted Enable bit
	1 = Inverted MBI is connected to AND gate
	0 = Inverted MBI is not connected to AND gate
bit 1	AAEN: AND Gate A1 A Input Enable bit
	1 = MAI is connected to AND gate
	0 = MAI is not connected to AND gate
bit 0	AANEN: AND Gate A1 A Input Inverted Enable bit
	1 = Inverted MAI is connected to AND gate

0 = Inverted MAI is not connected to AND gate

Register 40	-J. CMAFLIK.	Comparator Fi		Register			
U-0	U-0	U-0	U-0	U-0	U-0	U-0	I-0
—	—	—		—	—	—	—
bit 15							bit 8
U-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
_		CFSEL<2:0>		CFLTREN		CFDIV<2:0>	
bit 7							bit 0
Legend:							
R = Readab	ole bit	W = Writable b	bit	U = Unimplem	nented bit, rea	ad as 'O'	
-n = Value a	at POR	'1' = Bit is set		'0' = Bit is clea	ared	x = Bit is unkn	iown
	-4 CFSEL<2:0>: Comparator Filter Input Clock Select bits 111 = Reserved 110 = Reserved 101 = Reserved 100 = Reserved 011 = Reserved ⁽¹⁾ 010 = Timer2 Match ⁽¹⁾ 001 = PWM Special Event Trigger ⁽¹⁾ 000 = Instruction Clock (Fcr) ⁽¹⁾						
bit 3	CFLTREN: (1 = Digital fil 0 = Digital fil		out Digital Fil	ter Enable bit			
bit 2-0		Divide 1:32 Divide 1:16 Divide 1:8 Divide 1:4 Divide 1:2	utput Filter C	Clock Divide Sele	ect bits		

Register 48-5: CMxFLTR: Comparator Filter Control Register

Note 1: For more information, refer to the specific device data sheet.

U-0	U-0	U-0	U-0	U-0	R/W-0	R/W-0	R/W-0									
—	_	—	_	—	VREFSEL	BGSEL	<1:0>									
bit 15							bit 8									
R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0									
CVREN	CVROE ⁽¹⁾	CVRR	CVRSS		CVR<	3:0>										
bit 7							bit (
Legend:																
R = Readable	e bit	W = Writable	bit	U = Unimpler	mented bit, read	as '0'										
-n = Value at	POR	'1' = Bit is set		'0' = Bit is cle	ared	x = Bit is unkn	own									
bit 15-11	•	ted: Read as '														
bit 10		oltage Referen	ce Select bit													
		1 = CVREFIN = CVREF pin 0 = CVREFIN is generated by the resistor network														
bit 9-8	BGSEL<1:0>: Band Gap Reference Source Select bits															
511 5 0	11 = INTREF															
		10 = INTREF = 1.2V (nominal)														
		01 = INTREF = AVDD														
	00 = INTREF															
bit 7		parator Voltag														
	 1 = Comparator voltage reference circuit powered on 0 = Comparator voltage reference circuit powered down 															
bit 6		•			hit(1)											
	CVROE: Comparator Voltage Reference Output Enable bit ⁽¹⁾ 1 = Voltage level is output on CVREF pin															
	0 = Voltage level is disconnected from CVREF pin															
bit 5	CVRR: Comp	arator Voltage	Reference Ra	ange Selection	bit											
	1 = CVRsRc/24 step size															
	0 = CVRSRC/3	2 step size														
bit 4				Source Selection												
	 1 = Comparator voltage reference source, CVRSRC = AVDD – AVSS 0 = Comparator voltage reference source, CVRSRC = AVDD – AVSS 															
bit 3-0	•	•		e Value Selecti												
DIL 3-0	When CVRR	-	aye Reference	e value Selection												
			CVRSRC)													
	When CVRR		/				$CVREFIN = (CVR < 3:0 > /24) \bullet (CVRSRC)$									
		- 0.														

Register 48-6:	CVRCON: Comparator Voltage Reference Control Register
----------------	---

Note 1: The CVROE bit overrides the TRIS bit setting.

48.3 COMPARATOR OPERATION

The operation of a typical comparator, along with the relationship between the analog input levels and the digital output is illustrated in Figure 48-3. Depending on the comparator operating mode, the monitored analog signal is compared to either an external or internal voltage reference.

In Figure 48-3, the VIN-, is a fixed voltage. The analog signal present at VIN+ is compared to the reference signal at VIN-, and the digital output of the comparator is created by the difference between the two signals. When VIN+ is less than VIN-, the output of the comparator is a digital low level. When VIN+ is greater than VIN-, the output of the comparator is a digital high level. The shaded areas of the output represent the area of uncertainty due to input offsets and response time. The polarity of the comparator output can be inverted, so that it is a digital low level when VIN+ is greater than VIN-.





Input offset represents the range of voltage levels within which the comparator trip point can occur. The output can switch at any point within this offset range. Response time is the minimum time required for the comparator to recognize a change in input levels.

Each of the comparators can be configured to use the same or different reference sources. For example, one comparator can use an external reference while the others use the internal reference. For more information on operation of comparator voltage references, see **48.6** "Comparator Voltage Reference Generator".

48.4 COMPARATOR CONFIGURATION

Each of the comparators in the Comparator with Blanking module is configured independently by various control bits in the following registers:

- Comparator Status register (CMSTAT) (Register 48-1)
- Comparator Control register (CMxCON) (Register 48-2)
- Comparator Mask Source Control register (CMxMSKSRC) (Register 48-3)
- Comparator Mask Gating Control register (CMxMSKCON) (Register 48-4)
- Comparator Filter Control register (CMxFLTR) (Register 48-5)
- Comparator Voltage Reference Control register (CVRCON) (Register 48-6)

48.4.1 Comparator Enable/Disable

The comparator under control may be enabled or disabled using the corresponding CON bit (CMxCON<15>). When the comparator is disabled (CON = 0), the corresponding trigger and interrupt generation is also disabled.

It is recommended to first configure the CMxCON register with all bits to the desired value, and then set the CON bit (CMxCON<15>).

48.4.2 Comparator Output Blanking Function

In many power control and motor control applications, there are periods of time in which the inputs to the analog comparator are known to be invalid. The blanking (masking) function enables the user to ignore the comparator output during predefined periods of time. In this document, the terms 'masking' and 'blanking' are used interchangeably.

Figure 48-4 illustrates a block diagram of the comparator blanking circuitry. A blanking circuit is associated with each analog comparator.

Each comparator's blanking function has three user selectable inputs:

- MAI (Mask A Input)
- MBI (Mask B Input)
- MCI (Mask C Input)

The MAI, MBI and MCI signal sources are selected through the SELSRCA<3:0>, SELSRCB<3:0> and SELSRCC<3:0> bit fields in the CMxMSKSRC registers.

The MAI, MBI and the MCI signals are fed into an AND-OR function block, which enables the user to construct a blanking (masking) signal from these inputs.

The blanking (masking) function is disabled following a system Reset.

The HLMS bit (CMxMSKCON<15>) configure the masking logic to operate properly depending on the default (deasserted) state of the comparators.

If the comparator is configured for 'positive logic' so that a '0' represents a deasserted state and the comparator output is a '1' when it is asserted, the HLMS bit should bet set to '0' so that the blanking function (assuming the blanking function is active) will prevent the '1' signal of the comparator from propagating through the module.

If the comparator is configured for 'negative logic' so that a '1' represents a deasserted state and the comparator output is a '0' when it is asserted, the HLMS bit should be set to a '1' so that the blanking function (assuming blanking function is active) will prevent the '0' signal of the comparator from propagating through the module.



Figure 48-4: User Programmable Blanking Function Diagram

48.4.3 Digital Output Filter

In many motor and power control applications, the analog comparator input signals can be corrupted by the large electromagnetic fields generated by the associated external switching power transistors. Corruption of the analog input signals to the comparator can cause unwanted comparator output transitions. The programmable digital output filter can minimize the effects of input signal corruption.

The digital filter requires three consecutive input samples to be similar before the output of the filter can change state. Assuming the current state is '0', a string of inputs such as '001010110111' will only yield an output state of '1' at the end of the example sequence after the three consecutive '1's. Similarly, a sequence of three consecutive '0's are required before the output will change to a zero state.

Because of the requirement of three similar consecutive states for the filter, the chosen digital filter clock period must be one-third or less than the maximum desired comparator response time.

The digital filter is enabled by setting the CFLTREN bit (CMxFLTR<3>). The CFDIV<2:0> bits (CMxFLTR<2:0>) select the clock divider ratio for the clock signal input to the digital filter block. The CFSEL<2:0> bits (CMxFLTR<6:4>) select the desired clock source for the digital filter. The digital filter is disabled (bypassed) following a system Reset.

48.4.4 Comparator Polarity Selection

To provide maximum flexibility, the output of the comparator may be inverted using the CPOL bit (CMxCON<13>). This is functionally identical to reversing the inverting and non-inverting inputs of the comparator for a particular mode.

The CPOL bit (CMxCON<13>) should be changed only when the comparator is disabled (CON = 0). Internal logic will prevent the generation of any corresponding triggers or interrupts when CON = 0. The logic allows both the CON and CPOL bits to be set with a single register write.

48.4.5 Event Polarity Selection

In addition to a programmable comparator output polarity, the Comparator with Blanking module also allows software selection for trigger/interrupt edge polarity through the EVPOL<1:0> bits (CMxCON<7:6>). This feature allows independent control of the comparator output, as seen on any external pins, and the trigger/interrupt generation.

Note: The corresponding comparator must be enabled (CON = 1) for the specific trigger/interrupt generation to be enabled.

48.4.6 Comparator Reference Input Selection

The input to the non-inverting input of the comparator, also known as the reference input, can be selected between the following settings:

- CxINA pin (CON = 1, CREF = 0)
- Internal CVREF voltage (CON = 1, CREF = 1)

48.4.7 Comparator Channel Selection

The input to the inverting input of the comparator, also known as the channel input, can be selected between the following settings:

- CxINB pin (CON = 1, CCH<1:0> = 'b00)
- CxINC pin (CON = 1, CCH<1:0> = 'b01)
- CxIND pin (CON = 1, CCH<1:0> = 'b10)
- Band Gap Reference (CON = 1, CCH<1:0> = 'b11). The source of the band gap reference can be selected by the user-assigned application through the BGSEL<1:0> bits (CVRCON<9:8>).

48.4.8 Low-Power Selection

Depending on the capabilities of the comparator modules, this interface provides a low-power mode selection bit, CLPWR (CMxCON<12>). Using this bit, a user can trade-off power consumption for the speed of the comparator.

When CLPWR = 0, the Standard Power mode is active. When CLPWR = 1, the low-power setting of the corresponding comparator is enabled.

Note: The comparator power setting should not be changed while CON = 1.

48.4.9 Comparator Event Status Bit

The Comparator Event Status (CEVT) bit (CMxCON<9>) reflects whether or not the comparator has gone through the preconfigured event. After the bit is set, all future triggers and interrupts from the corresponding comparator will be blocked until the user-assigned application clears the CEVT bit. Clearing the CEVT bit begins rearming the trigger. Once the CEVT bit is cleared, it takes an extra CPU cycle for the comparator triggers to be fully rearmed.

48.4.10 Status Register

To provide an overview of all comparator results, the comparator output bits, CxOUT (CMxCON<8>) and the event bits, CxEVT (CMxCON<9>) are replicated as status bits in the CMSTAT register.

These bits are read-only and can be altered only by manipulating the corresponding CMxCON register or the comparator input signals. Figure 48-5 illustrates the comparator configurations.





48.5 COMPARATOR INTERRUPTS

The Comparator Interrupt Flag (CMIF) bit (IFS1<2>) is set when the synchronized output value of any of the comparator changes with respect to the last read value. The following bits can be read by the user application to detect an event:

- C1EVT Comparator 1 Event bit (CMSTAT<8>)
- **C2EVT** Comparator 2 Event bit (CMSTAT<9>)
- C3EVT Comparator 3 Event bit (CMSTAT<10>)

User-assigned software can read the CxEVT and CxOUT bits to determine the change that occurred. Because it is possible to write a '1' to this register, a simulated interrupt can be software initiated. Both the CMIF and CxEVT bits must be reset by clearing them in software. These bits can be cleared in the Interrupt Service Routine (ISR). For more information, refer to the **Section 8. "Interrupts"** (DS39707) in the "*PIC24F Family Reference Manual*".

Note: The comparison required for generating interrupts is based on the current comparator state and the last read value of the comparator outputs. Reading the C1OUT, C2OUT and C3OUT bits in the CMxCON register will update the values used for the interrupt generation.

48.5.1 Interrupt Operation During Sleep Mode

If a comparator is enabled and the PIC24F device is placed in Sleep mode, the comparator remains active. If the Comparator interrupt is enabled in the Interrupt module, it remains functional. Under these conditions, a comparator interrupt event will wake-up the device from Sleep mode.

Each operational comparator consumes additional current. To minimize power consumption in Sleep mode, turn off the comparators before entering Sleep mode by disabling the CON bit (CMxCON<15>). If the device wakes up from Sleep mode, the contents of the CMxCON register are not affected. For more information on Sleep mode, refer to **Section 10. "Power-Saving Features"** (DS39698) in the *"PIC24F Family Reference Manual"*.

48.5.2 Interrupt Operation During Idle Mode

The comparator remains active in Idle mode. Comparator interrupt operation during Idle mode is controlled by the Comparator Idle Mode (CMIDL) bit (CMSTAT<15>). If CMIDL = 0, normal interrupt operation continues. If CMIDL = 1, the comparator continues to operate, but it does not generate interrupts.

For more information on Idle mode, refer to **Section 10. "Power-Saving Features"** (DS39698) in the *"PIC24F Family Reference Manual"*.

48.5.3 Effects of a Reset State

A device Reset forces the CMxCON register to its Reset state, causing the comparator modules to be turned off (CON = 0). However, the input pins multiplexed with analog input sources are configured as analog inputs by default on device Reset. The I/O configuration for these pins is determined by the setting of the ADxPCFGL or ADxPCFGH register. Therefore, device current is minimized when analog inputs are present at Reset time.

48.5.4 Analog Input Connection Considerations

A simplified circuit for an analog input is illustrated in Figure 48-6. A maximum source impedance of 10 k Ω is recommended for the analog sources. Any external component connected to an analog input pin, such as a capacitor or a Zener diode, should have little leakage current.





48.6 COMPARATOR VOLTAGE REFERENCE GENERATOR

The internal comparator voltage reference is derived from a 16-tap resistor ladder network that provides a selectable voltage level, as illustrated in Figure 48-7. This resistor network generates the internal voltage reference for the analog comparators.

This voltage generator network is managed by the Comparator Voltage Reference Control (CVRCON) register (see Register 48-6) through these control bits:

- CVREN Comparator Voltage Reference Enable bit (CVRCON<7>) This control bit enables the voltage reference circuit.
- CVROE Comparator Voltage Reference Output Enable bit (CVRCON<6>) This control bit enables the reference voltage to be placed on the CVREF pin. When enabled, this bit overrides the corresponding TRIS bit setting.
- VREFSEL Voltage Reference Select bit (CVRCON<10>)
 This control bit specifies whether the reference source is external (VREF+), or it is obtained from the 4-bit DAC output.
- CVRSS Comparator Voltage Reference Source Selection bit (CVRCON<4>) This control bit specifies that the source (CVRSS) for the voltage reference circuit is either the device voltage supply (AVDD and AVSS) or an external reference (VREF+ and VREF-).
- CVRR Comparator Voltage Reference Range Selection bit (CVRCON<5>) This control bit selects one of the two voltage ranges covered by the 16-tap resistor ladder network:
 - 0 CVRSRC to 0.67 CVRSRC
 - 0.25 CVRSRC to 0.75 CVRSRC

The range selected also determines the voltage increments available from the resistor ladder taps (see **48.6.1 "Configuring the Comparator Voltage Reference**").

• CVR<3:0> - Comparator Voltage Reference Value Selection bits (CVRCOM<3:0>)

These bits designate the resistor ladder tap position.

Table 48-1 lists the voltage at each tap for both ranges with CVRSRC = 3.3V.





C)/D <2.05	Tere	Voltage Reference		
CVR<3:0>	Тар	CVRR = 0	CVRR = 1	
0000	0	0.83V	0.00V	
0001	1	0.93V	0.14V	
0010	2	1.03V	0.28V	
0011	3	1.13V	0.41V	
0100	4	1.24V	0.55V	
0101	5	1.34V	0.69V	
0110	6	1.44V	0.83V	
0111	7	1.55V	0.96V	
1000	8	1.65V	1.10V	
1001	9	1.75V	1.24V	
1010	10	1.86V	1.38V	
1011	11	1.96V	1.51V	
1100	12	2.06V	1.65V	
1101	13	2.17V	1.79V	
1110	14	2.27V	1.93V	
1111	15	2.37V	2.06V	

Table 48-1:Typical Voltage Reference with CVRSRC = 3.3V

48.6.1 Configuring the Comparator Voltage Reference

The voltage range selected by the CVRR bit (CVRCON<5>) determines the size of the steps selected by the CVR<3:0> bits (CVRCON<3:0>). One range (CVRR = 0) provides finer resolution by offering smaller voltage increments for each step. The equations used to calculate the comparator voltage reference are as follows:

 $\frac{\text{If } CVRR = 1:}{\text{Voltage Reference}} = ((CVR < 3:0 >)/24) * (CVRSRC)$ $\frac{\text{If } CVRR = 0:}{\text{Voltage Reference}} = (CVRSRC/4) + ((CVR < 3:0 >)/32) * (CVRSRC)$

48.6.2 Voltage Reference Accuracy/Error

The full voltage reference range cannot be realized because the transistors on the top and bottom of the resistor ladder network, as shown in Figure 48-7, keep the voltage reference from approaching the reference source rails. The voltage reference is derived from the reference source; therefore, the voltage reference output changes with fluctuations in the reference source. For reference voltage accuracy, refer to the "Electrical Characteristics" chapter of the specific device data sheet.

48.6.3 Operation During Sleep Mode

When the device wakes up from Sleep mode through an interrupt or a Watchdog Timer time-out, the contents of the CVRCON register are not affected. To minimize current consumption in Sleep mode, the voltage reference should be disabled.

48.6.4 Effects of a Reset

A device Reset has the following effects:

- Disables the voltage reference by clearing the CVREN bit (CVRCON<7>)
- Disconnects the reference from the CVREF pin by clearing the CVROE bit (CVRCON<6>)
- Selects the high-voltage range by clearing the CVRR bit (CVRCON<5>)
- Clears the CVR value bits (CVRCON<3:0>)

48.6.5 Connection Considerations

The voltage reference generator operates independently of the Comparator with Blanking module. The output of the reference generator is connected to the CVREF pin if the CVROE bit (CVRCON<6>) is set. Enabling the voltage reference output onto the I/O when it is configured as a digital input will increase current consumption. Configuring the port associated with CVREF as a digital output, with CVRSS enabled, will also increase current consumption.

The CVREF output pin can be used as a simple Digital-to-Analog output with limited drive capability. Due to this limited current drive capability, a buffer must be used on the voltage reference output for external connections to CVREF. Figure 48-8 illustrates a buffering technique example.





48

Comparator v Blanking

REGISTER MAP 48.7

A summary of the Special Function Registers (SFRs) associated with the Comparator with Blanking module

Table 48-2: **Comparator Register Map**

File Name	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit
CMSTAT	CMSIDL	—	—	—	_	C3EVT	C2EVT	C1EVT	—	—	—	—	—	C3C
CMxCON	CON	COE	CPOL	CLPWR	_	_	CEVT	COUT	EVPO	L<1:0>	_	CREF	_	
CMxMSKSRC	_	_	_	_	SELSRCC<3:0>				SELSRCB<3:0>					SEL
CMxMSKCON	HLMS	_	OCEN	OCNEN	OBEN	OBNEN	OAEN	OANEN	NAGS	PAGS	ACEN	ACNEN	ABEN	ABN
CMxFLTR	_	_	_	_	_	_	_	_	_	CFSEL<2:0>			CFLTREN	
CVRCON	_	_	_	_	_	VREFSEL	BGSE	L<1:0>	CVREN CVROE CVRR CVRSS			C		

Legend:

— = unimplemented, read as '0'. Reset values are shown in hexadecimal. Note 1: Not all bits are available for all devices. Please refer to the specific device data sheet for details.

48.8 DESIGN TIPS

Question 1:	Why is my voltage reference not what I expect?
Answer:	Any variation of the voltage reference source will translate directly onto the CVREF pin. Also, ensure that you have correctly calculated the voltage divider, which generates the voltage reference.
Question 2:	Why is my voltage reference not at the expected level when I connect CVREF into a low-impedance circuit?

Answer: The voltage reference module is not intended to drive large loads. A buffer must be used between the CVREF pin and the load of the PIC24F device (see Figure 48-8).

48.9 RELATED APPLICATION NOTES

This section lists application notes that are related to this section of the manual. These application notes may not be written specifically for the PIC24F device family, but the concepts are pertinent and could be used with modification and possible limitations. The current application notes related to the Comparator with Blanking module are:

Title

Application Note

Make a Delta-Sigma Converter Using a Microcontroller's Analog Comparator ModuleAN700A Comparator Based Slope ADCAN863

Note: Visit the Microchip web site (www.microchip.com) for additional application notes and code examples for the PIC24F family of devices.

48.10 REVISION HISTORY

Revision A (December 2010)

This is the initial released version of this document.

NOTES:

Note the following details of the code protection feature on Microchip devices:

- · Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV ISO/TS 16949:2002

Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, PIC³² logo, rfPIC and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rfLAB, Select Mode, Total Endurance, TSHARC, UniWinDriver, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2010, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

Printed on recycled paper.

ISBN: 978-1-60932-735-4

Microchip received ISO/TS-16949:2002 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



Worldwide Sales and Service

AMERICAS

Corporate Office 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: http://support.microchip.com Web Address:

www.microchip.com

Atlanta Duluth, GA Tel: 678-957-9614 Fax: 678-957-1455

Boston Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL Tel: 630-285-0071 Fax: 630-285-0075

Cleveland Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

Dallas Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Kokomo, IN Tel: 765-864-8360 Fax: 765-864-8387

Los Angeles Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto Mississauga, Ontario, Canada Tel: 905-673-0699 Fax: 905-673-6509

ASIA/PACIFIC

Asia Pacific Office Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong Tel: 852-2401-1200 Fax: 852-2401-3431 Australia - Sydney Tel: 61-2-9868-6733

Fax: 61-2-9868-6755 China - Beijing

Tel: 86-10-8528-2100 Fax: 86-10-8528-2104

China - Chengdu Tel: 86-28-8665-5511 Fax: 86-28-8665-7889

China - Chongqing Tel: 86-23-8980-9588 Fax: 86-23-8980-9500

China - Hong Kong SAR Tel: 852-2401-1200 Fax: 852-2401-3431

China - Nanjing Tel: 86-25-8473-2460 Fax: 86-25-8473-2470

China - Qingdao Tel: 86-532-8502-7355 Fax: 86-532-8502-7205

China - Shanghai Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

China - Shenyang Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

China - Shenzhen Tel: 86-755-8203-2660 Fax: 86-755-8203-1760

China - Wuhan Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

China - Xian Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

China - Xiamen Tel: 86-592-2388138 Fax: 86-592-2388130

China - Zhuhai Tel: 86-756-3210040 Fax: 86-756-3210049

ASIA/PACIFIC

India - Bangalore Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

India - New Delhi Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

Japan - Yokohama Tel: 81-45-471- 6166 Fax: 81-45-471-6122

Korea - Daegu Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur Tel: 60-3-6201-9857 Fax: 60-3-6201-9859

Malaysia - Penang Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila Tel: 63-2-634-9065 Fax: 63-2-634-9069

Singapore Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan - Hsin Chu Tel: 886-3-6578-300 Fax: 886-3-6578-370

Taiwan - Kaohsiung Tel: 886-7-213-7830 Fax: 886-7-330-9305

Taiwan - Taipei Tel: 886-2-2500-6610 Fax: 886-2-2508-0102

Thailand - Bangkok Tel: 66-2-694-1351 Fax: 66-2-694-1350

EUROPE

Austria - Wels Tel: 43-7242-2244-39 Fax: 43-7242-2244-393 Denmark - Copenhagen Tel: 45-4450-2828

Fax: 45-4485-2829 France - Paris Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany - Munich Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Italy - Milan Tel: 39-0331-742611 Fax: 39-0331-466781

Netherlands - Drunen Tel: 31-416-690399 Fax: 31-416-690340

Spain - Madrid Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

UK - Wokingham Tel: 44-118-921-5869 Fax: 44-118-921-5820